


Framing Information: 98HH Front (Double Glass)

ORTAL
YOUR LIFE. YOUR FIRE

Framing Dimensions




Model	A	B	C	D
98HH Front	49 1/2"	106 1/2"	21 5/8"	Refer to Vent Manufacturer's Firestop Dimensions

Note: 1. Drawings are not to Scale
 2. All dimensions in inches
 3. No weight can be transferred to the fireplace. ALL FRAMING MUST BE SELF-SUPPORTED.

Framing Information: 98HH Front (Double Glass)

ORTAL
YOUR LIFE. YOUR FIRE

Framing Details




The valve can be moved 36" from the center of the fireplace in any direction.

- Note: 1. Drawings are not to Scale
2. All dimensions in inches
3. No weight can be transferred to the fireplace. ALL FRAMING MUST BE SELF-SUPPORTED.

Framing Information: 98HH Front (Double Glass)



Fireplace Dimensions



Model	(H) Height	(W) Width	(D) Depth	C1	C2	C3	Viewing Area	
							Front	Side
98HH Front	49 1/2"	106 1/2"	21 5/8"	7 7/8"	53 1/4"	12 5/16"	97 5/16" W X 29 1/2" H	—

Note: 1. Drawings are not to Scale
 2. All dimensions in inches